

## NATUROIL 3115 Oil Modified Low Sheen

NATUROIL 3115 Oil Modified Low Sheen is a single pack, clear, oil based floor coating.

### Product Advantages

- Overcomes the risk of edge bonding on tongue & groove
- Enhances the natural look of the timber
- Low sheen
- Excellent flow and levelling results in smooth finish
- Enhanced the natural colour of timber without appearing 'plastic'

### Typical Applications

Interior use only. Timber, particleboard, cork flooring and sports floors.

*Not recommended for use on coloured cork, limed or very light timber species. Not suitable for exterior or wet area applications e.g. bathrooms or around swimming pools. Caution: floor will be slippery when wet.*

### Product Properties

Build:	Medium
Sandability:	Very Good
Solvent Resistance:	Good
Water Resistance:	Very Good
Levelling & Flow:	Excellent

### Typical Properties

Colour:	Brown in can, dries clear
Gloss:	Low Sheen

### Product Approvals

NATUROIL 3115 has been evaluated for AS/NZS 4586:2004: Slip resistance classification of new pedestrian surface materials by Advanced Technology Testing & Research (ATTAR). The coating system passed the requirements of the "Dry Slip Resistance" and was classified as Dry = F. Certificates available on request.

AS/NZS 4586:2004 Slip resistance classification of new pedestrian surface materials – Appendix D (Oil-Wet Ramp Slip Resistance). Classification group = R12. Certificates available on request.

**Coverage:** 10-12 m<sup>2</sup> per litre

*Coverage is dependent upon the porosity of the substrate.*

**Thinning:** Not required.

### Application Methods:

Equipment: 6mm mohair roller and high quality brush

Preparing the floor to a professional standard is essential to achieve the best results.

- Fill all nail holes with a water based putty, allow to dry.

- Sand uncoated floor with 120-150 grade sandpaper or screenback on a flexible pad to ensure floor is uniformly dull with no sanding scratches, nibs or fur. Vacuum thoroughly. Take care to avoid scratching the surface.
- Timber Floor: Apply a liberal first coat of NATUROIL 3100 or FASTASEAL 3030 Sealer using a 6mm mohair roller and good quality brush to cut in. If using FASTASEAL allow to dry for 45 minutes before sanding, for all other coatings allow to dry overnight (min 16 hours).
- Cork Floor: Apply a liberal first coat of FASTASEAL 3030 Sealer using a 6mm mohair roller and good quality brush to cut in. Allow to dry for 45 minutes before sanding.
- Thoroughly sand floor with 150-180 grade sandpaper or screenback, remove all nibs, fluff and fur. Vacuum all dust.
- Apply a second coat of NATUROIL 3100. Allow to dry (min 16 hours).
- Thoroughly sand floor with 150-180 grade sandpaper or screenback, remove all nibs, fluff and fur. Vacuum all dust.
- Apply the final coat of NATUROIL 3115 Low Sheen.

*Note: Only pour sufficient coating to complete the job, replace the lid immediately as exposure to the environment can cause the product quality and performance to be affected. Do not return unused product to the can as this will cause the remaining material to increase in viscosity.*

**Drying:** Hard Dry: Overnight – the surface may be subjected to light traffic after 24 hours  
 Full Cure: 5 - 7 days (during this period floors should not be walked on with shoes).  
 Care should be taken to avoid dragging furniture over the surface, use protective pads on furniture legs.

*Low temperatures and heavy film thickness will retard drying times and cause frying upon application of subsequent coats. Direct sunlight and draft during drying may affect the final gloss level of the coating.*

NATUROIL 1499 Accelerator may be used to speed up the dry time of NATUROIL 3115 Low Sheen. Add 50 mls of NATUROIL 1499 Accelerator per litre of NATUROIL 3115 Low Sheen. Only mix as much as would be used in one day.

**Recommended Sealers:** NATUROIL 3100 Gloss  
 FASTASEAL 3030 Sealer

**Shelf Life:** 24 months, see label for use by date.

**Packaging:** 10 litres

**Refer to the NATUROIL Product Information Guide for more information.**

### Health & Safety

Before handling, refer to the Material Safety Data Sheet for health and safety information. Ensure that all personnel using this product have read and understood this data sheet and the associated MSDS and packaging label before using this product.

Note: Coatings give off strong solvents and odours during the drying process. People and pets should be removed from the building during the application and drying of coatings. All food and fabrics should also be removed to reduce the risk of them becoming tainted during the drying process.

---

Mirotone Pty Ltd Australia (Head Office)  
 ABN 40 000 041 136  
 21 Marigold Street, Revesby NSW 2212, Australia, P +61 2 9795 3700 F +61 2 9771 3601  
 sales@mirotone.com.au

[www.polycure.com.au](http://www.polycure.com.au)